

*450.100 THERMO BLENDER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY	Remark
1	ZBC630-1001A	Casing-New	1	For KA21226 & BC630-101-1
2	ZBC630-1002	Knob (For BC630-100-EG)	1	
2-1	ZBC630-1002-1A	Encoder-New (For BC630-100-EG)	1	For KA21226
2	ZBC630-1002A	Knob (For BC630-101-1)	1	For BC630-101-1 KA22045
2-1	ZBC630-1002A-1	Encoder (For BC630-101-1)	1	
2	ZBC630-1002B	Knob (For BC630-101-1) -New	1	For BC630-101-1 After KA23011
3+4+5+6+7	ZBC630-1003Z	Mixing Bowl Assembly (handle+bottom+)	1	
3	ZBC630-1003	Base of Bowl	1	
4	ZBC630-1004	Mixing Bowl With Handle (#304)	1	
4-1	ZBC630-1004-1	Mixing Bowl Only (#304)	1	
4-2	ZBC630-1004-2	Handle	1	
5	ZBC630-1005Z	Lid(Include Ring) (PP+Glass Fiber)	1	
	ZBC630-1005-1	Lid's sealing Ring(Silicon)	1	
6	ZBC630-1006	Mixing Blade (Knife #304)-Old	1	For KA20300& KA19294&KA21226&KA22045
6	ZBC630-1006A	Mixing Blade (Knife #304)-New	1	For BC630-101-1 After KA23011
7	ZBC630-1007	Mixing Blade Ring	1	
8	ZBC630-1008	Measuring cup (PC(LG))	1	
9	ZBC630-1009	Basket(PP)	1	
10	ZBC630-10010	Spatula (Silicon)	1	
11	ZBC630-10011	Mixing Whisk (Nylon+Glass Fiber)	1	
12+13+14	ZBC630-10012Z	Steamer Assembly	1	
12	ZBC630-10012	Steamer Bottom (PP)	1	
13	ZBC630-10013	Steamer Frame (PP)	1	

*450.100 THERMO BLENDER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY	Remark
14	ZBC630-10014	Steamer Cover(PC)	1	
1, 2, 2-1, A01 (1~4)	ZBC630-100-A01-1Z	LCD Screen With PCB Assembly (1~4)+Knob+Encoder+Casing -New (For BC630-100-EG)	1	For KA20300& KA19294
A01 (1~4)	ZBC630-100-A01-1	LCD Screen With PCB Assembly-New (1~4) (For BC630-100-EG)	1	For KA21226
A01-1	ZBC630-100-A01-1A	PCB Board For Screen -New (For BC630-100-EG)	1	
A01-2	ZBC630-100-A01-2A	LCD Screen -New (For BC630-100-EG)	1	
A01-3	ZBC630-100-A01-3A	Touch Screen -New (For BC630-100-EG)	1	
A01-4	ZBC630-100-A01-4A	Screen Frame And Knob-New (For BC630-100-EG)	1	
A01 (1~4)	ZBC630-100-A01A	LCD Screen With PCB Assembly(1~4) (For BC630-101-1)	1	For BC630-101-1 KA22045
A01 (1~4)	ZBC630-100-A01B	LCD Screen With PCB Assembly(1~4) (For BC630-101-1) -New	1	For BC630-101-1 After KA23011
A01-1	ZBC630-100-A01B-1	PCB Board For Screen (For BC630-101-1) -New	1	
A01-2	ZBC630-100-A01B-2	LCD &Touch Screen (For BC630-101-1) -New	1	
A01-4	ZBC630-100-A01B-4	Screen Frame And Knob (For BC630-101-1) -New	1	
A02	ZBC630-100-A02	PCB Board For Motor	1	
A03	ZBC630-100-A03	Motor 230V/50Hz,500W -Old	1	For KA20300& KA19294&KA21 226&KA22045
A03	ZBC630-100-A03A	Motor 230V/50Hz,500W -New	1	For BC630-101-1
A06	ZBC630-100-A06A	Fan-New After 2020.09	1	
A07	ZBC630-100-A07	Motor Crash Pad	4	
A08	ZBC630-100-A08	Leg	3	
A09	ZBC630-100-A09A	Weigh-New(3Pcs) After 2020.09	3	
-	ZBC630-100-A10	Motor Connector -Old	1	For KA20300& KA19294&KA21 226&KA22045
A10	ZBC630-100-A10A	Motor Connector &Cover -New	1	For BC630-101-1
-	ZBC630-100-A11	Motor Connector Cover -Old	1	For KA20300& KA19294&KA21 226&KA22045

*450.100 **THERMO BLENDER** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY	Remark
A11-1	ZBC630-100-A11-1	Transmission Rubber	1	For BC630-101-1
A12	ZBC630-100-A12	Blade Cover (Optional Accessories)	1	
A13	ZBC630-100-A13	Bowl Needle Loop	1	
A14	ZBC630-100-A14	Motor Waterproof Pad	1	
A15	ZBC630-100-A15A	Needle Stock-New	1	
A16	ZBC630-100-A16	Waterproof Plate	1	
A17	ZBC630-100-A17	Magnetic Valve	1	
A18	ZBC630-100-A18	Baseboard	1	
A19	ZBC630-100-A19	Emergency Button	1	
A20	ZBC630-100-A20	Side Plate 1	1	
A21+A19	ZBC630-100-A21B	Side Plate 2 With Emergency Button Before 2020.09	1	
A21	ZBC630-100-A21A	Side Plate 2 -New After 2020.09	1	
A22	ZBC630-100-A22	Micro-Switch Of Lid	1	
A23	ZBC630-100-A23	Drive Plate Of Weigh -After 2021.06	1	For KA21226 &BC630-101-1