

688.005 / 688.055 **FRITEUSE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZCE700-126K1	Power Indicator	1
2	ZCE700-126K2	Heating Indicated	1
3	ZCE700-126K3	Temperature Limiter 240°C	1
4	ZCE700-126K4	Terminal Block	1
5	ZCE700-126K5	Black Plate of Electric Box	1
6	ZCE700-126K6	Micro Switch	1
7	ZCE700-126K7	Power Cord Jacket	1
8	ZCE700-126K8	Electrical Parts Box	1
9	ZCE700-126K9	Power Cord	1
10	ZCE700-126K10	M12 Nut	2
11	ZCE700-126K11	Temperature Sensor Clip	6
12	ZCE700-126K12	Heat Element Board	1
13	ZCE700-126K13	Heating Element 2000W	1
14	ZCE700-126K14	Temperature Sensor Clip	4
15	ZCE700-126K15	Oil Tray	1
16	ZCE700-126K16	Copper Screw	1
17	ZCE700-126K17	Handle Of Bottom Box	2
18	ZCE700-126K18	Knob With Bezel	1
19	ZCE700-126K19	Thermostat-China 190°C	1
20	ZCE700-126K20	Fryer Basket Hanger	1
21	ZCE700-126K21	Handle of Oil tank Cover	1

688.005 / 688.055 **FRITEUSE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
22	ZCE700-126K22	Cover for Oil Pot	1
23	ZCE700-126K23	Fryer Basket	1
24	ZCE700-126K24	Fried Network Bracket	1
25	ZCE700-126K25	Bottom Box (Single)	1
	ZCE700-126K25-1	Bottom Box (Double)	1
26	ZCE700-126K26	Feet	4
-	ZCE700-126K-A01-1	Electric Terminal Box Associate Parts	1