

688.217 MICROWAVE OVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
A00	ZCE4106-A000	Cavity Assembly	1
A01	ZCE4106-A001	Splash Cover	1
A10	ZCE4106-A010	Plate Cover *Inner Assembly	1
A16	ZCE4106-A016	Thermostat Brkt	2
B01	ZCE4106-B001	Baseplate	1
C00	ZCE4106-C000	"Control Box Assembly With PCB"	1
-	ZCE4106-C000-1	"Control Box Assembly Without PCB"	1
C01	ZCE4106-C001	Control Panel	1
C02	ZCE4106-C002	C/Panel Decoration	1
C03	ZCE4106-C003	C/Panel Decoration-Left	1
C04	ZCE4106-C004	C/Panel Decoration-Right	1
C05	ZCE4106-C005	Membrane Switch	1
C18	ZCE4106-C018	Power PCB	1
C19	ZCE4106-C019	Metal Bracket	1
C26	ZCE4106-C026	Light Guide	1
C72	ZCE4106-C072	Display PCB	1
D00	ZCE4106-D000	Door Assembly	1
D01	ZCE4106-D001	Door Frame Drop Glue Assembly	1
D02	ZCE4106-D002	Latch	2
D03	ZCE4106-D003	Spring -Top	1
	ZCE4106-D003-1	Spring -Bottom	1
D06	ZCE4106-D006	Door Screen	1
D07	ZCE4106-D007	Door Panel	1
D08	ZCE4106-D008	Door Gasket	1
D09	ZCE4106-D009	D/Panel Decoration	1

688.217 MICROWAVE OVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
D14	ZCE4106-D014	Handle	1
D23	ZCE4106-D023	Door Shaft	2
E01	ZCE4106-E001	Magnetron	2
E04	ZCE4106-E004	Lamp	1
E05	ZCE4106-E005	H.V.Transformer	2
E06	ZCE4106-E006	H.V.Capacitor	2
E07	ZCE4106-E007	H.V.Diode	2
E15	ZCE4106-E015	Noise Fliter	1
E11	ZCE4106-E011	Fuse	2
E16	ZCE4106-E016	Power Cord	1
E37	ZCE4106-E037	Thermostat 150°C	2
E44	ZCE4106-E044	Thermostat 120°C	1
F14	ZCE4106-F014	Plastic Bracket	1
L00	ZCE4106-L000	Interlock Assembly	1
L01	ZCE4106-L001	Latch Board	1
L03	ZCE4106-L003	Micro Switch	3
L04	ZCE4106-L004	Micro Switch	2
L05	ZCE4106-L005	Main Wire Harness	1
L06	ZCE4106-L006	Latch Spring	1
L07	ZCE4106-L007	Interlock Lever A	1
L08	ZCE4106-L008	Interlock Lever B	1
L09	ZCE4106-L009	Interlock Lever C	1
M06	ZCE4106-M006	Filter Net	1
R10	ZCE4106-R010	Back Plate Assembly	1
T01	ZCE4106-T001	Synchronous Motor	2

688.217 MICROWAVE OVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
T26	ZCE4106-T026	Metal Cover	1
T48	ZCE4106-T048	Stirrer Fan Assembly U	1
T48+Z39	ZCE4106-T048Z	Stirrer Fan Assembly+Plastic Nail *2 U	1
T49	ZCE4106-T049	Stirrer Fan Assembly L	1
T48+Z39	ZCE4106-T049Z	Stirrer Fan Assembly+Plastic Nail *2 L	1
W00-L	ZCE4106-W000L	Fan Assembly-Left	1
W00-R	ZCE4106-W000R	Fan Assembly-Right	1
W08	ZCE4106-W008	Wind Guide U	1
W09	ZCE4106-W009	Wind Guide L	1
W15	ZCE4106-W015	Air Duct U	1
W16	ZCE4106-W016	Air Duct L	1
W17	ZCE4106-W017	Mounting Plate	1
W20	ZCE4106-W020	Wind Guide Cover Assembly	1
Y28	ZCE4106-Y028	Plastic Bracket	1
Y38	ZCE4106-Y038	Metal Cover	2
Y47	ZCE4106-Y047	Foot Cushion Block	6
Z01	ZCE4106-Z001	Capacitor Holder	2