



Dear customer,

We would like to congratulate you on the purchase of this first-class ROTPUNKT vacuum flask, designed to be used to keep drinks or liquids hot or cold.

We would like to give you a few tips for its use so that you can continue to enjoy using your 'Made in Germany' product for as long as possible.

Product features

The glass lining of your new vacuum flask is made of high-quality, double-layered, hand-made glass. Between the two layers of glass are a vacuum and a reflective silver layer of precious metal, which together guarantee that the flask will retain heat very effectively and have a long product life, providing it is not damaged. This innovative combination makes your flask extremely robust against both interior and exterior damage.

Our specification for the glass used: R.P.-h/3 S glass (impact and shock resistant, thick walls).

Before first use

Before using your new thermos for the first time, we recommend giving it a warm rinse with any conventional detergent, followed by two or three rinses with clear (not boiling) water.

Use

We recommend that you avoid extreme or sudden changes in temperature! This may lead to damage to the insulation function and damage to the glass lining.

Important information

- Please NEVER drink directly from the flask, but rather use a receptacle which you pour your drink into (danger of scalding!)
- Avoid the use of metallic objects (e.g. metal spoons or similar)
- Each time you use the vacuum flask, examine it for potential damage beforehand.
- Not suitable for microwave.
- Not dishwasher-safe (see "Cleaning").
- Do not use the vacuum flask to keep milk products or baby food warm (danger of bacteria).
- The flask is not intended to be used for medicinal or experimental purposes.
- Do not let your children use this vacuum flask without supervision.

Keeping drinks warm

In order to keep your drink warm for up to 24 hours, first rinse the flask with warm water and then fill it with hot water. After approx. 5 minutes, pour out the water and fill up the flask with your chosen hot drink.

Keeping drinks cold

In order to keep your drink cold for up to 36 hours, fill the flask with cold water before filling with your chosen cold drink. After approx. 5 minutes, pour out the water and fill up the flask with your chosen cold drink. Under no circumstances should ice cubes be put in the flask for additional cooling! After 36 hours, the liquid temperature rises by max. 3°C.

Preparing tea in the flask


Put the tea bag directly into the flask (do not use a metal tea infuser!) and hang the string over the handle. Your tea can now develop its aroma for the suggested number of minutes.

Brewing aromatic coffee

Most commercially available coffee filters will fit on many ROTPUNKT vacuum flasks.

Filling up to the right level

Do not fill up your flask right to the top (Beware! Danger of scalding through overflowing liquid!). Leave around 2cm space to the top edge of the glass container. You should also avoid the screw top being immersed in the drink.



Simple pouring

Turn the screw top half a turn to the left whilst holding the flask in a vertical position. You can now tilt the flask slowly forwards and start to pour out the drink.

Water-tightness

Please only use the vacuum flask in an upright position. Close the flask by putting on the screw top and turning it to the right. We recommend turning the lid once more after 5 minutes. The seal pressure of your new flask should be regularly tested after use and can be increased again by turning the base of the flask to the right. For products with a base screw, tighten it gently and carefully.

Cleaning

To clean your vacuum flask correctly, use a soft cloth or sponge to clean the flask, glass lining and the screw-top lid under warm, running water. On no account should you use alcohol or methylated spirits!

Tip: when using with tea or coffee, use our special cleaning pearls (you can get these on our online shop at www.rotpunkt4u.de)! Precise information for use can also be found on our website.

Streaks

Streaks in the glass are technically possible, but have no effect on the usability/ isolation function or on the quality of the glass lining.

Repair and spare parts

After impact or dropping the flask, you should inspect the product immediately for damage. For the repair of damaged goods (at your expense), please send the defective product –carefully packed– to:



We request that you download the PDF document „Repair Order“ and fill this in and send it with the product.

You can find this at www.rotpunkt4u.de/manuals

Replacement parts (such as glass linings/screw top lids/sealing rings) can be ordered by phone. For fast identification of your model, you can find the product number on the base of your vacuum flask.

